

Start Stop Periodic Transmission with IL

Version 1.3 2007-08-14

Application Note AN-ISC-2-1035

Author(s) Gunnar Meiss

Restrictions Restricted membership

Abstract Start and stop a periodical transmission of the Interaction Layer.

Table of Contents

1.0	How to start and stop periodic transmission	1
1.1	Manufacturer, Hardware platform, derivative	
1.2	Problem Description	
1.3	Problem Solution	1
1.3.1	Additional Configuration of the Interaction Layer in CANgen	2
1.3.2	Configuration of the Interaction Layer in GENy	3
1.3.3	Additional Functions Provided by the Interaction Layer Kernel	3
2.0	Contacts	5

1.0 How to start and stop periodic transmission

1.1 Manufacturer, Hardware platform, derivative

There are no dependencies between manufacturer, hardware platform and derivative according to this problem.

1.2 Problem Description

After the transmission path of the IL was started (IITxStart()) the transmission of cyclic message takes place. Nothing further is needed to be done to keep the transmission running. The cycle time must be pre-configured in the network database at compile time. Some applications need to stop and restart the periodic transmission for individual messages.

1.3 Problem Solution

The periodical transmission can be stopped and restarted by the application optionally. Therefore the Interaction Layer provides some additional service functions. The function IIStopCycle(<IIMessageHandle>) stops the periodic transmission of a message, the function IIStartCycle(<IIMessageHandle>) restarts the periodic transmission.

Each call of the function IITxStart() starts the cyclic transmission. In some cases it might be necessary to avoid the cyclic transmission after IITxStart(). Therefore it is possible to call the function IIStopCycle(<IIMessageHandle>) within the callback function ApplIITxStart(). This disables the cyclic transmission of a message immediately after IITxStart(). In this case the cyclic transmission will not be started for this message.



Caution

This API shall never be performed on Messages containing multiplexed signals.



1.3.1 Additional Configuration of the Interaction Layer in CANgen




Figure 1 - Configuration of the Interaction Layer in the Generation Tool

Figure 1 shows a screen shot of the configuration tool CANgen. Within the tab IL options the Interaction Layer could be configured. The relevant option on this tab is shown in the table below.

Parameter	Value	Meaning	Reference
Use start/stop	On/Off	This option is necessary if periodic transmission should	
of periodic		be stopped and restarted during runtime.	
messages			

Table 1 – II options tab



1.3.2 Configuration of the Interaction Layer in GENy




Figure 2 – Start/Stop API in GENy

Figure 2 shows a screen shot of the configuration tool GENy. On the configuration view of **II Vector** the Interaction Layer could be configured. The Start/Stop API is the relevant option you have to activate if periodic transmission should be stopped and restarted during runtime.

1.3.3 Additional Functions Provided by the Interaction Layer Kernel

Name:	IIStartCycle
Standard Prototype:	void IIStartCycle (IITransmitHandle iITxHnd);
Multi Channel	void IIStartCycle_X(IITransmitHandle iITxHnd);
Prototype:	with X = 0 Number of CAN channel
Indexed	void IIStartCycle (IITransmitHandle iITxHnd);
Prototype:	
Argument(s):	ilTxHandle IL Handle of the messages for with the cyclic transmitted should be restarted
	The generated < <i>IIMessageHandle></i> shall be used:
	In CANgen (ilpar.h):
	_ILTx <messagename></messagename>
	In GENy (il_par.h):
	IlTxMsgHnd <messagename></messagename>
Return:	None
Description:	This function restarts the periodical transmission of a message and shall be called
	on task level. Due to this that all timing counters are set in the state transition tx start
	the callback function ApplIITxStart may be used to implement the changed cycle
	time behavior.

Table 2 - Description of IIStartCycle

Name:	IIStopCycle
Standard	void IIStopCycle (IITransmitHandle iITxHnd);
Prototype:	



Multi Channel	void IIStopCycle_X(IITransmitHandle iITxHnd);
Prototype:	with X = 0 Number of CAN channel
Indexed	void IIStopCycle (IITransmitHandle iITxHnd);
Prototype:	
Argument(s):	ilTxHandle IL Handle of the messages for with the cyclic transmitted
	should be stopped
	The generated I/MessageHandle> shall used:
	In CANgen (ilpar.h):
	ILTx <messagename></messagename>
	In GENy (il_par.h):
	IlTxMsgHnd <messagename></messagename>
Return:	None
Description:	This function stops the periodical transmission of a message and shall be called on task level.

Table 3 – Description of IIStopCycle



2.0 Contacts

Vector Informatik GmbH

Ingersheimer Straße 24 70499 Stuttgart Germany

Tel.: +49 711-80670-0 Fax: +49 711-80670-111 Email: info@vector-informatik.de

Vector France SAS

168 Boulevard Camélinat 92240 Malakoff

France
Tel: +33 (0)1 42 31 40 00
Fax: +33 (0)1 42 31 40 09
Email: information@vector-france.fr

Vector CANtech, Inc.

39500 Orchard Hill Pl., Ste 550

Novi, MI 48375

USA Tel: +1-248-449-9290

Fax: +1-248-449-9704 Email: info@vector-cantech.com

Vector Japan Co. Ltd.

Seafort Square Center Bld. 18F 2-3-12, Higashi-shinagawa,

Shinagawa-ku J-140-0002 Tokyo Tel.: +81 3 5769 6970 Fax: +81 3 5769 6975

Email: info@vector-japan.co.jp

VecScan AB

Lindholmspiren 5 402 78 Göteborg Sweden

Tel: +46 (0)31 764 76 00 Fax: +46 (0)31 764 76 19 Email: info@vecscan.com